


Encoder Scaled to give 1 /rev




Press home spindle button on screen to start spindle homing. LED goes green during homing. Start spindle with M4 S200, then stop with M5. Spindle will now be homed.

Pyvcp.home.spindle

home spindle
spindle homing (green)

Pyvcp.led.0



Normal operating speed

Spindle enable/clockwise

Spindle anti clockwise

float
S32