



Do Not insert W1. VIN and VFIELD need to be separate power supplies isolated from each other.  
Power VField with 5V.

Title			Homann Designs		
Size: A3	Number:	Revision:	20 View St VIC		
Date: 19/05/2019	Time: 2:54:22 PM	Sheet of	Australia 3190		
File: C:\Users\peter\OneDrive\Documents\Projects\G32X Backpack\devel\artwork\G320X Reset.SchDoc					