

Sheet1

NVEM	remora.input	NVEM	remora.output
Switched to	+12	OUT-1	remora.output.0
FHA	remora.input.0	OUT-2	remora.output.1
FHB	remora.input.1	OUT-3	remora.output.2
SRO	remora.input.2	OUT-4	remora.output.3
SJR	remora.input.3	OUT-5	remora.output.4
STOP	remora.input.4	OUT-6	remora.output.5
PROB	remora.input.5	OUT-7	remora.output.6
INP3	remora.input.6	OUT-8	remora.output.7
INP4	remora.input.7	OUT-9	remora.output.8
INP5	remora.input.8	OUT-10	remora.output.9
INP6	remora.input.9		remora.output.10
INP7	remora.input.10		remora.output.11
INP8	remora.input.11		remora.output.12
INP9	remora.input.12		remora.output.13
INP10	remora.input.13		remora.output.14
INP11	remora.input.14		remora.output.15
INP12	remora.input.15		
		VSO	remora.SP.0
Switched to	GND		
10X	remora.input.23		
ESTOP	remora.input.25		
B-IN			
X-IN	remora.input.16		
100X	remora.input.24		
1X			
C-IN	remora.input.21		
A-IN	remora.input.19		
Y-IN	remora.input.17		